



INSTRUCTIONS SAGGING MATTRESS SUPPORT



Step (1)

First, know what type of mattress you have. Only works on Innerspring and Latex mattresses up to 14" thick. DOES NOT WORK on Tempur-Pedic, Memory Foam mattress, air, water or sofa bed mattress. Read and learn how to do this before you order.



Step (2)

Measure the depth of your sag using a yardstick and tape measure as shown in photo.

You will insert this between your mattress and box to directly target the sagging area on an INNERSPRING or LATEX mattress only up to 14" thick.



Step (3)

Choose either the 1" thick Standard (or) the 1 ½" thick Standard Deep. You want a level sleeping surface, choose the thickness that matches your sag depth measurement.

Standard Deep. The manufacturing process utilizes a 2-ply heat fused material to make the 1.5" thickness

SagsAway cannot work with memory foam because the effect of the support is absorbed rather than transferred.

TARGET the visible sag or weak spot to push up and fill in from under your mattress for the SAG DEPTH you measured.

BEGIN with (1) for each person or sag. Try One – Test Your Results first for your mattress type, sag size and sag depth. Instructions and a phone number for support are included. If you don't achieve the results others have, give us a call with your measurements.

*The manufacturing process utilizes a 2-ply heat fused material to make the 1.5" thickness.

If you have the wrong type of mattress – it will be non-responsive and will not work because the effect of the support is absorbed rather than transferred.